

## Heavy Duty Anchor System

### INSTALLATION INSTRUCTIONS

Please read instructions COMPLETELY before assembly.



**DO NOT RETURN PRODUCT TO THE STORE**  
Missing parts, replacement parts, or assembly help, please contact customer service:  
**714-367-3000 or 877-922-6679**

### WARNING!

Use Caution during installation. Safety goggles are recommended. Please read the instructions carefully before installation. This is only a TEMPORARY shelter and is not recommended for permanent use.

Keep all flame and heat sources away from this fabric.


Do not set-up or leave the canopy unattended in the following conditions: gusty wind, rain, hail, sleet, snow, drizzle, or any other harsh weather conditions. Doing so may cause damage to the entire canopy and will void the warranty. Please call Caravan® Global for any questions or inquiries

Caravan® Canopy Sports  
14600 Alondra Blvd  
La Mirada, CA 90638, USA  
877-9-CANOPY • 714-367-3000  
www.caravansports.com




### Package Contents

- 6 - Steel Anchors
- 6 - Ropes




Steel Anchors



Ropes

### WARNING!

1. Always inspect the canopy and each part before use. Make sure that everything is tightly secured. Replace any worn, defective or missing parts.
2. After installation, the canopy should be anchored to prevent damage and possible injury. It is the user's responsibility to properly anchor the product.



### STEP 1 ATTACH ROPES TO TOP

Tie ropes to the top at the lower exterior grommet points. These exterior grommet points are located near the top of each leg.

### STEP 2 PLACEMENT OF ANCHORS

These anchors are not to be put into solid grounds like asphalt, concrete or wood. Place the anchors into the ground, making sure that the ropes can be tied to the eyelet of the anchor. Using a downward and clockwise motion, drill the anchor into the ground until it is secure.

### STEP 3 SECURE ROPES

Tie the ropes to the eyelet of the anchor.

